

VINGA
SWEDEN



CARE & USE

CARE

- Microwave your wheat bag for one and a half minutes, turn over, then microwave again for approximately another minute.
- Note: Times may vary depending on your microwave wattage.
- Always place a cup of water in the microwave with wheat bag when heating.
- Always test the temperature before applying to the affected area.
- Always allow your wheat bag to cool completely before reheating. Do not overheat the wheat bag. Watch for signs of over heating e.g. an over-cooked smell or burning or charring and in extreme cases, smoking. These all indicate that irreversible grain deterioration has occurred. Safely dispose of your wheat bag immediately.
- Warning - Do not leave heated wheat bags unattended.
- We recommend you replace your wheat bags annually.