

VINGA
SWEDEN



CARE & USE

CARE

Wash inside of decanter/carafe with warm soapy water and rinse prior to first use.

Avoid storing food or beverages in glass containers for extended periods of time.

Change liquid contents of all glass containers frequently. This will help preserve the products finish, avoid film build-up and the chemical erosion of the interior surface.

Do not store the glasses on top of each other, this may scratch or crack the glass.